



EOS

Inspired by Los Angeles' sunrises and named after a goddess of dawn, these ethereal pillars of digital light arouse the senses with hundreds of soothing colors. EOS are hand-made in limited edition runs. The aluminum base blends well in any decor, and the frosted acrylic pillar projects and diffuses light. Press

a button on the remote and change the mood, luminosity, or pulse from across the room. Connect several EOS lamps and move animated patterns of light from one to the next through any space.

Materials: Acrylic and aluminum
Designers: Visopia LLC

ASSEMBLY INSTRUCTIONS

AN ELEVEN STEP PROGRAM TO VISUAL UTOPIA

1. We recommend unpacking your new Eos floor lamp on a soft surface to avoid scratching its surface.
2. Open Base (smaller) box, remove protective packaging from Base, and stand upright.
3. Lay the Tube (longer) box flat on floor. Open and remove protective ribs from Tube. Leave the plastic sleeve on the Tube to prevent getting fingerprints on the Tube.
4. Place Tube on soft surface, near Base. Never leave the Tube standing unless it's attached to the Base; otherwise you risk adding a big crack to the Tube. (We don't think it'll look as nice.)
5. Connect the cable coming from the bottom of the Tube to the cable inside the Base.
6. Carefully lift and place Tube on Base, making sure not to pull on cable. Make sure your fingers don't get pinched between the Tube and the Base. (Ouch!)
7. Tighten each set screw a little bit at a time with the included allen wrench, making sure to center the Tube. To move your Eos floor lamp, squat down and carefully tip it towards your chest and shoulder area. Then lift it using both hands from beneath the Base. Or use a dolly; that works too. Please don't lift your Eos floor lamp by the Tube. If you do you might end up with a color-changing foot! (Ouch)
8. Connect power supply to power connector in the Base's slot
9. Remove protective plastic sleeve from Tube
10. Plug power supply into wall outlet.
11. Grab a comfy seat and begin the show!

OPERATING INSTRUCTIONS




Figure 1. Remote Control Diagram

After turning on the lamp by pressing button S5, buttons S4 and S2 let you select one of fourteen solid colors or animated pattern (respectively) for the lamp. Buttons S1 and S3 modify the palette and speed of an animation.

Button S5 turns the lamp and off. Sometimes be necessary to press buttons S4 or S2 after turning the lamp off to turn off all of the lamp units inside the EOS.

TABLE 1. TECHNICAL SPECIFICATIONS

DESCRIPTION		
Model Number	EOS7	
Weight	42	lbs
Dimensions	72 high x 6 dia	inches
Power	100-240	Volts
	0.5	Amps

LuzLab
 E/Sales@LuzLab.com
 T/+1.323.225.1065
 620 Moulton Ave, Ste 111
 Lincoln Heights, California 90031